



Supplement

Title: CLKT Installation Guide

Supplement Issue: **2**

Part Number: 4251231

Issue Date: 4/17

Print Date: June. 2010, Rev. 1, 3/11

Change #1

On the first page:

Change: CLKT, CLKTO, CLK

To: CLKT

On the first page, after the first paragraph, replace the sentence and Table 1 with:

The item in Table 1 is applicable to this Installation Guide.

Table 1

Model	Application	Type	Size
CLKT	Indoor/Outdoor	3, 12	2", 3", 4"

On the 7th page, under Step 10, replace the last two sentences with:

Gradually advance each fixing until the gasket is seen to compress evenly.

On the 8th page, replace the entire page with:

Gasket Compression

Tighten taptite screws until gasket compresses between 0.3-0.5 mm (0.012"-0.020"). Do not overtighten screws.

Note

Take all measurement with digital vernier calipers.

Change #2, 438

On the first page, replace the ***Introduction*** with:

Introduction

The ClirVu IR Window allows the flexibility to inspect an electrical enclosure both visually and with infrared. Use the accessory on the flat surface of a Type 1, 2, 3/12, 3 or 4/12 enclosure, or as appropriate. All models are for indoor and outdoor use. Table 1 is a list of the models available from Fluke.