


USER MANUAL


Big Digit Indoor/ Outdoor Hygro-Thermometer MODEL 445713



1 Introduction

The Extech 445713 features a dual LCD display for simultaneous indication of indoor and outdoor relative humidity and temperature (°C/°F selectable). The MAX/MIN memory displays the highest and lowest readings. Proper use and care of this meter will provide years of reliable service.

2 Description



- 1. Indoor temperature and humidity
- 2. Outdoor temperature and humidity
- 3. MAX/MIN button
- 4. MAX/MIN RESET button
- 5. Remote probe
- 6. Wall mount
- 7. Probe compartment
- 8. Tilt stand
- 9. Battery compartment
- 10. Temperature units switch
- 11. Battery compartment cover

3 Operation

- Open the battery compartment by pushing the cover on the rear of the instrument downward, as indicated by the arrow. Remove the battery safety strip and replace the cover. Remove the protective film on the LCD display. The instrument is now ready for use.
- 2. Select the temperature units using the switch on the rear of the instrument.
- The upper display indicates the indoor humidity and temperature. The lower display indicates the outdoor humidity and temperature (using the remote probe).
- 4. Recalling the maximum and minimum readings:
 - Press the MAX/MIN button to view the highest values measured since the RESET button was last pressed.
 - Press the MAX/MIN button again to view the lowest values measured since the RESET button was last pressed.
 - Press the MAX/MIN button again to return to normal operation.
- 5. To reset (clear) the MAX/MIN memory:
 - Press the RESET button for 1 second (while in the MAX/MIN display mode) to clear and reset the memory.
- The unit can be wall-mounted or placed on a flat surface using the fold-out footing.
- The low battery flag will appear on the display when the battery voltage is low.

4 Battery Replacement

Open the battery compartment by sliding the battery cover on the rear of the instrument downward as indicated by the arrow. Replace the 1.5 V 'AAA' battery and secure the cover.

Do not dispose of used batteries or rechargeable batteries in household waste.

5 Specifications

Measurement	Range	Accuracy
Temperature	14 to 140°F (-10 to 60°C)	±1.8°F (±1°C) from 14 to 122°F (–10 to 50°C)
Relative Humidity	10 to 99%	± 5% RH from 25 to 85% RH at 73°F (23°C)
Battery	1.5 V 'AAA' cell	

6 Customer Support

Customer Support Local Telephone List:

https://support.flir.com/contact

Returns (RMA):

https://customer.flir.com/Home

7 Warranty

Teledyne FLIR warrants this Extech brand instrument to be free of defects in parts and workmanship for two years from date of shipment. To view the full warranty text, please visit the support site, link below.

https://www.flir.com/support-center/warranty/



USER MANUAL

Website

http://www.flir.com

Customer support

http://support.flir.com

Copyright

© 2025, FLIR Systems, Inc. All rights reserved worldwide.

Disclaimer

Specifications subject to change without further notice. Models and accessories subject to regional market considerations. License procedures may apply. Products described herein may be subject to US Export Regulations. Please refer to exportquestions@flir.com with any questions.

Publ. No.: NAS100272
Release: AB
Commit: 104817
Head: 104820
Language: en-US
Modified: 2025-05-02
Formatted: 2025-05-02

